



STOLER INDUSTRIES

ALLSTATE VULCANIZED RUBBER BASE & STAIRTREADS
BOX 2587 DALTON, GA 30722
PH 706 277-1000 FAX 706 277-4400

MAINTENANCE ON ALLSTATE VULCANIZED RUBBER BASE:

Allstate vulcanized/thermo set rubber base generally

requires little maintenance.

Allstate rubber base may be cleaned with a soft chamois

cloth or if necessary

A paste wax can be applied.

PLEASE NOTE: The application of a paste wax will increase the gloss level of the product.